# 1.6 Mega CMOS camera ID1M6B-CL (B/W) ID1M6C-CL (Color)

**Product Specification** 

**iDule CORPORATION** 

# table of contents

		PAGE
1.	Product Details	3
2.	Composition	3 3
3.	Handling precautions	4
4.	Main Standards 4.1. General Major Standards 4.2. Camera Input/Output Signal Standards	5
5.	External Connection Connector Specifications	9 9
6.	Timing Chart	
	6.1. 2Tap Base Configuration Horizontal synchronization	
	<ul><li>6.2. 2Tap Base Configuration Vertical synchronization</li><li>6.3. 3Tap Base Configuration (HS mode) Horizontal synchronization</li></ul>	
	6.4. 3Tap Base Configuration (HS mode) Vertical synchronization.	
	6.5. 2Tap Base Configuration (Decimation and Binning Mode) Horizontal synchronization	
	6.6. 2Tap Base Configuration (Decimation and Binning Mode ) Vertical synchronization	13
	6.7. 3Tap Base Configuration (Decimation and Binning Mode , HS Mode) Horizontal synchronization	
	6.8. 3Tap Base Configuration (Decimation and Binning Mode, HS Mode) Vertical synchronization	
	6.9. Image Output Formats	
	6.10. Fixed Trigger Shutter Mode	
7.	Scanning Mode	
	7.1. Partial Scan Mode	
	<ul> <li>7.2. 1/2 Horizontal and Vertical Decimation Mode</li></ul>	
_		
8.	8bit HS mode (High Speed Mode)	
9.	Serial communication function	
	9.1. Command description	
	9.2. Control example	
10.	Function setting (Sets the function of the camera using serial communication. )	35
11.	Dimensions	39
12.	Factory Settings	40
13.	Warranty Coverage	41
14.	About CMOS pixel defects	41
15.	Product Services	41

# 1. Product Details

This camera is a Camera Link camera that uses a 6.3 mm diagonal and a 1.6 Mega CMOS image sensor made by Sony. The time required to read out all pixels is 1/150.7s when 3Tap Base Configuration (HS mode) is output.

# Features

- □ Global shutter CMOS sensor
- □ Fixed Trigger Shutter Mode, Pulse Width Trigger Shutter Mode
- □ Input power (12pin connector or PoCL)
- 8-bit HS mode (High Speed Mode) supports high frame rate output
   \*The amount of saturated signal of the image sensor is 1/4
- □ 1/2 Horizontal and Vertical Thinning Mode Implementation Frame Rate Improvement
- □ 2 × 2 Horizontal and vertical pixel binning mode implementation Frame rate enhancement \*ID1M6B-CL (B&W) only
- □ Full frame rate and resolution of video output

	•	
2Tap Base Configuration	100.47 fps	8bit / 10bit / 12bit
Decimation and binning mode	319.97 fps	8bit / 10bit / 12bit
3Tap Base Configuration	150.71 fps	8bit (HS mode)
Decimation and binning mode	523.58 fps	8bit (HS mode)

# 2. Composition

- 2.1. Standard Configuration
  - □ Camera body

# 2.2. Free Software

iDule Control Panel (software)

# 2.3. Packing Specifications

- □ Individual carton
- □ Master carton (20 units)

#### 3. Handling precautions

Important: Please observe the following precautions in order to use the camera correctly. Any failure or malfunction of the camera caused by incorrect use without following these precautions is not covered by the product warranty.

This unit cannot be used for devices whose failure or malfunction may directly threaten human life or cause harm to human beings (equipment for special applications such as nuclear power and aerospace).

• To protect the camera, do not use in dusty or humid places.

· Handle the camera carefully so as not to subject it to strong shocks or static electricity. Failure to do so may result in a malfunction.

- To protect the CMOS image sensor, do not directly capture images from direct sunlight or high-intensity light. Also, when not in use, please put a protective seal on it.
- To connect to the camera, see "5.Please follow the instructions for "External Connection Connector Specifications". Please note that the wrong connection may not only damage the camera itself, but also cause irreparable damage to the connected device.
- If there is an AC leak from the device (monitor, computer, etc.) connected to the camera, the camera may be damaged. After fully checking the ground potential between the two parties, make sure that there is no problem before connecting.
- ·Use the camera's power supply voltage correctly within the specifications. If you use a power supply that does not meet the specifications or an unstable power supply, the camera may malfunction or malfunction.
- When turning the camera back on, wait at least 2 seconds before turning it on.
- •Camera input power supply DC+12V $\pm$  10% ripple should be supplied within  $\pm$ 50mV. It may appear as noise in the image signal.
- •Please make sure that there is no noise such as chatter when the power supply starts.

# 4. Main Standards

# 4.1. General Major Standards

(1)	Image sensor	Imaging Type	6.3mm	diagonal global shutter (Sor	ny IMX273)
		Total number of pixels		H) x 1098(V)	
		Pixel size	-	m(H) x 3.45 μ m(V)	
		Image Circle	Φ6.291		62 <sup>9</sup> 1 3.788 5.023 (単位:mm)
(2)	Video Output			All-pixel mode	
	Frequency	CLK Frequency	85MHz		
		Output Effective Pixels	1456(H	H) x 1088(V)	
		2Tap Base Configuration		100.47fps	748 (H) x 1088 (V) : Including blanking
		3Tap Base Configuration		150.71fps HS Mode	499 (H) x 1088 (V) : Including blanking
				Decimation and binn	ing mode
		CLK Frequency	85MHz		
		Output Effective Pixels	728(H)	) x 544(H)	
		2Tap Base Configuration		319.96fps	453 (H) x 586 (V) : Including blanking
		3Tap Base Configuration		523.58fps HS Mode	277 (H) x 586 (V) : Including blanking
(3)	Video Output	2Tap Base Configuration	Interlea	ave	
	System	3Tap Base Configuration	Interlea	ave	
(4)	Output Format	Sensor AD	12bit, 8	8bit (HS mode)	
		Camera Link output	-	l0bit / 12bit	
				S mode (High Speed Mode)	
				mount of saturated signal of the	image sensor is 1/4
(5)	Sensitivity	B/W	F4	2000lx	
		Color	F2.8	2000lx	
		· · · · · · · · · · · · · · · · · · ·	de, Shu	tter speed 1/100.47s(OFF), (	Gain 0dB, 2Tap Base Configuration)
(6)	Minimum	B/W	F1.4	13lx	
	Illumination	Color	F1.4	26lx	
					Gain +12dB, 2Tap Base Configuration)
(7)	Power Input	DC+12V±10% (12pin C	onnecto	or or PoCL)	
	Voltage				
(8)	Power	type 1.5 W			
	Consumption	max 1.8 W			
(9)	Dimensions	H:29.0mm W:29.0mm D	:29.0m	m excluding projection	
<u> </u>	Weights	Approx. 50g			
(11)	Lens Mounts	C-mount			

(12) Gain			$0dB \sim +12dB$	
(13) Shutter speed			All-pixel mode	
	2Tap Base Confi	guration	1/40000s ~ OFF(1/100.47s)	
	3Tap Base Conf	guration	1/45000s ~ OFF(1/150.71s) : HS mode	
			Decimation and binning mode	
	2Tap Base Confi	guration	1/51000s ~ OFF(1/319.97s)	
	3Tap Base Confi	guration	1/57000s ~ OFF(1/523.58s) : HS mode	
(14) Slow shutter			All-pixel mode	
	2Tap Base Conf	guration	OFF(1/100.47s) ~ 2.538s	
	3Tap Base Conf	guration	OFF(1/150.71s) ~ 1.699s : HS mode	
			Decimation and binning mode	
	2Tap Base Conf	guration	OFF(1/319.97s) ~ 800.1ms	
	3Tap Base Configuration 0		OFF(1/523.58s) ~ 488.9ms : HS モード	
(15) Trigger Mode	Fixed shutter tri	Fixed shutter trigger mode , Pulse width shutter trigger mode		
(16) Partial Scanning	Full Frame Rate	~ 4 lines (4 line	es/step) 2 partial areas	
(17) Safety Quality	CE	Emission: E	N61000-6-4:2007+A1:2011	
Standards		1	N61000-6-2:2005	
	RoHS Directive			
(18) Durability	Vibration		acceleration 98m/s2 (10G), X, Y, Z in each direction tes in each direction).	
	Shock			
		-	able to withstand impacts.	
(19) Environment	Operating		$^{\circ}$ C Humidity 0 ~ 90%RH However, it should not condense.	
conditions	Temperature			
	Storage	-25°C~+	65°C Humidity 0 ~ 90%RH However, it should not condense.	
	temperature			

# 4.2. Camera Input/Output Signal Standards

(1)Video Output Data	Effective video output	1456(H) × 1088(V)	(in full-frame scan mode)	
(2) Synchronous signal LVAL		Camera Link output(LVDS)		
output	FVAL			
	DVAL			
	SP J			
	(Exposure signal)			
(3) Camera Control Signal Input	CC2·CC3·CC4	Camera Link input (LVDS)	(Unused)	
(4) Trigger signal input	CC1	Camera Link intput (LVDS)	(Switchable to CN1 input at address 06)	
	polarity	Positive Polarity/Negative	(Polarity switchable at address 05)	
		Polarity		
	Pulse width	1HD (minimum) ~ about 2 frames		
(5) Serial communication	SerTC	Camera Link input (LVDS)		
	(Serial to Camera)			
	SerTFG	Camera Link output (LVDS)		
	(Serial to FrameGrabber)			
(6) Video signal	White Clip Level	FFEh	(Gain 0dB, 12bit)	
	Setup Levels	060h or less		
	Dark shading	00Fh or less		
(7) Trigger signal CN1 input	CN1:11 pins	Low1.4V(max),High3.3V~5.0V	(Can be switched to CC1 input at address 06)	
(8) Exposure signal CN1 CN1 : 6 pins		Low0.55V (max), High3.8V		
output		(minimum)		
(9) FVAL signal CN1output	CN1:7 pins	Low0.55V (max), High3.8V		
		(minimum)		

Trigger signal CN1 input circuit



Exposure signal CN1 output, FVAL signal CN1 output circuit



4.3. Spectral Sensitivity Characteristics \*Excludes lens characteristics and light source characteristics.



ID1M6C-CL



- 5. External Connection Connector Specifications
  - 5.1. Camera Link Connector 12226-1100-00PL (3M)



# Connector (P1)

pin	Name	pin	Name
numb		num	
er		ber	
1	+12V(PoCL)	14	GND
2	X0-	15	X0+
3	X1-	16	X1+
4	X2-	17	X2+
5	Xclk-	18	Xclk+
6	X3-	19	X3+
7	SerTC+	20	SerTC-
8	SerTFG-	21	SerTFG+
9	CC1- (Trigger IN -)	22	CC1+ (IN+ Trigger)
10	CC2+	23	CC2-
11	CC3-	24	CC3+
12	CC4+	25	CC4-
13	GND	26	+12V(PoCL)

 $\ast$  Do not supply power from both P1 and CN1.

# 5.2. Power LED

Lights up when the camera is operational. If there is no power supply or the camera is faulty, the LED will not light up. \* With the serial setting, the LED can be turned off (address 1B).

5.3. 12-pin connector HR10A-10R-12PB(74) (Hirose) equivalent (CN1)

Pin	name
Number	
1	GND
2	Power supply (DC+12V)
3	GND
4	NC
5	GND
6	Vertical simultaneous output
	(FVAL signal)
7	Exposure signal
8	GND
9	NC
10	NC
11	Trigger Signal Input
12	GND



 $\ast$  Do not supply power from both P1 and CN1.

# 6. Timing Chart

6.1. 2Tap Base Configuration Horizontal synchronization



# 6.2. 2Tap Base Configuration Vertical synchronization



6.3. 3Tap Base Configuration (HS mode) Horizontal synchronization



6.4. 3Tap Base Configuration (HS mode) Vertical synchronization



6.5. 2Tap Base Configuration (Decimation and Binning Mode) Horizontal synchronization



6.6. 2Tap Base Configuration (Decimation and Binning Mode ) Vertical synchronization



6.7. 3Tap Base Configuration (Decimation and Binning Mode, HS Mode) Horizontal synchronization



6.8. 3Tap Base Configuration (Decimation and Binning Mode , HS Mode) Vertical synchronization



# 6.9. Image Output Formats

1) All-pixel mode

2Tap Base Configuration



ID1M6C-CL



3Tap Base Configuration (HS mode) ID1M6B-CL



ID1M6C-CL R1 G2 R3 · · · · R G R G / / G B G B G B / /

# 2) Decimation and Binning mode

2Tap Base Configuration ID1M6B-CL



3Tap Base Configuration (HS mode) ID1M6B-CL



ID1M6C-CL \* Decimation mode only



# 6.10. Fixed Trigger Shutter Mode

- □ This mode starts exposure with a trigger signal input from an external source, and sets the exposure time with a serial communication command.
- □ Exposure Time Delay from detecting the trigger edge inside the camera to starting exposure



□ Trigger input is also accepted during the image output period.

However, do not enter a trigger signal for the exposure setting that causes the next image output to start before the image output is completed.

□ Trigger inputs during the Exposure Time are ignored in the camera. (Figure (A) below)



Trigger Hsync Mode When set to OFF, the delay time before starting exposure is fixed.
 However, when used in an operation that starts exposure during image output (overlap readout operation),

Depending on the input timing of the trigger, the exposure start line may appear as line noise.

6.11. Pulse Width Trigger Shutter Mode

- □ This mode starts the exposure with a trigger signal input from the outside, and sets the exposure time according to the width of the trigger signal.
- □ Exposure Time Delay from the time the trigger edge is detected inside the camera until the exposure starts or ends



 $\Box$  Pulse width 1HD (minimum) ~ about 2 frames.

In terms of function, there is no upper limit, but during long exposures, noise such as dark noise and shading may be noticeable.

If the pulse width is shorter than 1HD, the exposure time is controlled with an upper limit of 1HD.

□ Trigger input is also accepted during the image output period.

However, do not enter a trigger signal for the exposure setting that causes the next image output to start before the image output is completed.



18

□ Trigger Hsync Mode When set to OFF, the delay time before starting exposure is fixed.

However, when used in an operation that starts exposure during image output (overlap readout operation),

Depending on the input timing of the trigger, the exposure start line may appear as line noise.

- 7. Scanning Mode
- 7.1. Partial Scan Mode
  - $\hfill\square$  It is possible to set up to two partial areas with serial communication commands.
  - $\hfill\square$  Cannot be used in conjunction with thinning/addition mode.

Partial Scan Settings		
Scanning Modes	Address : 8	Data: 1
Partial Scan Start Position 1	Address : 40 –41	
Partial Scan Start Position 2	Address : 42 –43	
Partial Scanning Number of Effective Lines1	Address : 50 –51	
Partial Scanning Number of Effective Lines2	Address : 52 –53	

Example: When two partial areas are set



- □ When setting up multiple partial scan areas, set the starting position and effective line so that the areas do not overlap.
- $\Box$  For the partial start position and partial area, set the **value to 4 x n**.
- □ Total number of lines in frames
  - = V Number of blanking lines (fixed at 42H) + Number of Partial Scan effective lines

However, partial scanning must satisfy the number of effective lines <= 1088 .

 $\Box$  Frame rate = 1 / (total number of lines in frames  $\times$  time of 1 line)

1 line time =

2Tap Base Configuration : 8.808us

3Tap Base Configuration (HS Mode) : 5.872us

# □ Configuration Examples

	frame	Frame	e Rate
Number of Effective Lines	Total number of lines	2Tap Base Configuration	3Tap Base Configuration (HS)
4H (minimum).	46H	2468.1fps	3702.2fps
•			
272H	314H	361.57fps	542.36fps
•			
544H	586H	193.74fps	290.61fps
•			
816H	858H	132.32fps	198.48fps
•			
1088H (Max: Full Frame)	1130H	100.47fps	150.71fps

7.2. 1/2 Horizontal and Vertical Decimation Mode

- □ The number of pixels (amount of data transferred) can be reduced without changing the angle of view.
- □ ID1M6B-CL (B/W) outputs horizontal and vertical pixels every other pixel.
- □ ID1M6C-CL (Color) outputs horizontal and vertical pixels every two pixels in units of RG and GB.
- $\hfill\square$  The frame rate is faster than all pixel output.
- □ Max shutter time : 2Tap Base Configuration 1/319.97s、 3Tap Base Configuration (HS mode) 1/523.58s

2

Setting the 1/2 Horizontal and Vertical Decimation Mode

Scanning Modes	Address: 8	Data:
----------------	------------	-------

ID1M6B-CL



ID1M6C-CL



7.3. 2×2 Horizontal and Vertical Pixel Binning Mode \* ID1M6B-CL only

- □ The number of pixels (amount of data transferred) can be reduced without changing the angle of view.
- □ 2 horizontal pixels and 2 vertical pixels are added to 1 pixel for output.
- $\hfill\square$  The frame rate is faster than all pixel output.
- □ Max shutter time : 2Tap Base Configuration 1/319.97s, 3Tap Base Configuration (HS mode) 1/523.58s
- □ Only ID1M6B-CL (black and white) can be operated.

2 × 2 Setting the horizontal and vertical pixel Binning mode

Scanning Modes

Address: 8 Data: 3



- 8. 8bit HS mode (High Speed Mode)
  - □ 3Tap Base Configuration **150.71fps**, 523.58fps in **decimation and addition mode**, and high frame rate output is possible.
  - □ Compared to the normal 8-bit, 10-bit, and 12-bit output, the amount of saturated signal of the image sensor is 1/4.
  - Compared to the normal 8bit/10bit/12bit output, the sensitivity level output from the camera is 4 times higher,

and the signal-to-noise ratio is 4 times worse.

2Tap Base Configuration	8bit / 10bit / 12bit	100.47 fps
Decimation and addition mode	8bit / 10bit / 12bit	319.97 fps
3Tap Base Configuration	8bit (HS mode)	150.71 fps
Decimation and addition mode	8bit (HS mode)	523.58 fps



# 9. Serial communication function

Communication settings	
baud rate	: 9600bps (Default)
data	:8bit
Stop Bits	:1bit
parity	: none
XON/XOFF	: No control

• Transmit Command Format (Host  $\rightarrow$  Camera)

Send the command and parameters with STX and ETX appended.

STX	command	Parameters (ASCII code)	ETX
(02H)	(2 bytes)	(20H-7FH)	(03H)

• Response Format (Camera  $\rightarrow$  Host)

The camera responds with control codes ACK, NAK.

If the response includes a text message, a telegram will be sent with STX and ETX appended.

ACK
(06H)

NAK

(15H)

··· Abnormal termination

··· Successful completion

STX	command	Parameters (ASCII code)	ETX	•••• Message reply
(02H)	(2 bytes)	(2FH- 7FH)	(03H)	

# List of commands

command	function
SR	Register Writes
GR	Register Reading
HIS	User Data Writing
GU	User Data Loading
CS	Config Save
CR	Config Store *
QM	Get a model name
QS	Serial Number Acquisition
QV	Firmware version acquisition
Ν	Get Error Details

\* After running the config-up store, restart the camera.

# 9.1. Command description

# 1) Register value setting

## [Command] Set : Register

	STX	S	R	(a)	(a)	(d)	(d)		ETX	
				add	ress	Data (va	ariable lei	ngth: up	to 16 ado	lresses)
les	ponse]				_					
	Success	ful	•••	ACK						

[Re

Successful	•••	ACK
completion		
Communication		NAK
Errors		

# [Explanation]

Rewrites the register value at the specified address.

The data is of variable length, and you can set up to 16 addresses of data starting with the specified address.

2) Register Value Retrieval



[Explanation]

Retrieves the register value for the specified address. The number of data acquisitions is specified as '0'~'F' (hexadecimal). If the number of acquisitions is set to '0', data for 16 addresses will be sent, and if omitted, data for 1 address will be sent.

# 3) User data settings



# [Explanation]

The user can freely write the string. 1 table, 4 tables with 16 characters can be used.

# 4) User Data Acquisition



# 5) Register information storage

[Co	[Command] Config : Save					
	STX	С	S	ETX		

[Response]

-		
Successful	•••	ACK
completion		
Communication	•••	NAK
Errors		

6) Register information restoration (factory setting)

[Command] Config : Restore

STX C R ETX
-------------

[Response]

Successful		ACK
completion		
Communication	•••	NAK
Errors		

After executing the command, restart the camera.

# 7) Get Model Name

[Command] Query: I	Model Na	ame						
STX Q	М	ETX						
[Response]								
Successful completion		STX	R	М	(d)	(d)		ETX
				I	Model r	name (fix	ed length	n: 16 bytes)
Communication Errors		NAK				·	-	

8) Serial Number Acquisition



28

# 9) Firmware version acquisition

[Command]	Query: \	Version								
STX	Q	V	ETX							
[Response] Successf	ul		STX	R	V	(d)	(d)	٦	ETX	
completi					v	(u)	(u)			
completi										
						Version i	informa	ation (fix	ed lengtl	n: 8 bytes)
Commun Errors	ication		NAK							, ,
10) Get Erro	or Detail	S								
[Command]	Query: I	Error								
STX	Q	And	ETX							
[Response]										
Successf	ul		STX	R	And	(d)		(d)	(d)	ETX
completi	on									

ssification detail

		classification
Communication ····	NAK	
Errors		

	classification		detail
0:	No Errors	00:	normal
1:	Communication Protocol	00:	Undefined Commands
	Error	01:	Command Length Abnormality
		02:	Address value anomaly
		03:	Data value anomalies
		04:	Length value abnormality
		05:	Table No. Value Anomaly
		06:	User data string anomaly
2:	Internal control error	00:	Internal control fault
		01:	Write to read-only address
		02:	Write to write-protect address
		03:	Out-of-control access
		04:	Abnormal in the selected table number
		05:	There is an abnormality in the set value
			of the average value acquisition area.
		06:	Feature not implemented

# 9.2. Control example

1) Check the status of the trigger shutter mode. (Lead address 04)

[Send Comr	nand]											
	STX	G	R	0	4	ETX						
				$\subseteq$	)							
Address04												
[Car	nera resp	onse]										
							STX	А	R	0	1	ETX
										$\square$		
Data 01												
			-									

[Response received]

Since the 01 was answered, the fixed trigger shutter mode.

2) Examine the manual gain settings. (Read 2 consecutive bytes from address 20)



[Response received] 02FF (767) was replied to, so +12dB. 3) Set to partial scan mode. (Write 01 to 08)

[Send Comr	nand]									
	STX	S	R	0	8	0	1	ETX		
Address 08	Data 01									
[Can	nera resp	onse]							AC	К
[Response r The ACK wa 4)	is answer					e 24FF to	o address	s 01)		
[Send Comr	nandl									
	STX	S	R	2	4	F	F	0	1	ETX
Address 24	Data 01F	F							_	
[Can	nera resp	onse]							AC	K
[Response r	eceived]		•							

The ACK was answered, so the configuration was successful.

5) Save the camera settings. (Send CS command)

[Send Command]	
STX C S ETX	
[Camera response]	
L	ACK
	-
[Response received]	
The ACK was answered, so the configuration was successful.	
6) Restore the camera to factory settings. (Send CR command)	
[Send Command] STX C R ETX	
SIA C R LIA	
[Camera response]	
	ACK
	-
↓	
[Response received]	

The ACK was answered, so the configuration was successful.

7) Get the details of a communication error.



[Response received]

Type 1, Detail 02 was replied to, so an address value abnormal error occurred.

				-					
10	Function	cottina	(Sate tha	function	of the	camora ucir	a corial	communication.	١.
10.	1 unction	setting		runction	or the	camera usi	iy senai	communication.	)

function	Address (Hex)	Data (Hex)							
Preset Shutter	01	All-pixel mode							
			2Tap Base	3Tap Base					
			Configuration	Configuration (HS)					
		00:	1/100.47s(OFF)	1/150.71s(OFF)					
		01:	1/200s	1/200s					
		02:	1/250s	1/250s					
		03:	1/500s	1/500s					
		04:	1/750s	1/750s					
		05:	1/1000s	1/1000s					
		06:	1/2500s	1/2500s					
		07:	1/5000s	1/5000s					
		08:	1/7500s	1/7500s					
		09:	1/10000s	1/10000s					
		0A:	1/20000s	1/20000s					
		0B:	1/30000s	1/30000s					
		0C:	1/40000s	1/40000s					
		0D:	1/40000s	1/45000s					
		0E:	1/40000s	1/45000s					
		0F:	Manual shutter (see addresse	es 24-25)					
			Decimation and Binning Mode						
			2Tap Base	3Tap Base					
			Configuration	Configuration (HS)					
		00:	1/319.97s(OFF)	1/523.58s(OFF)					
		01:	1/500s	1/750s					
		02:	1/750s	1/1000s					
		03:	1/1000s	1/2500s					
		04:	1/2500s	1/5000s					
		05:	1/5000s	1/7500s					
		06:	1/7500s	1/10000s					
		07:	1/10000s	1/20000s					
		08:	1/20000s	1/30000s					
		09:	1/24000s	1/33000s					
		0A:	1/28000s	1/37000s					
		0B:	1/33000s	1/42000s					
		0C:	1/40000s	1/48000s					
		0D:	1/51000s	1/57000s					
		0E:	1/51000s	1/57000s					
		0F:	Manual shutter (see addresse	es 24-25)					

function	Address (How)		Data (Hav)					
function	Address (Hex)	00.	Data (Hex)					
Preset White Balance	02	00:	THRU					
(Color only)		01:	3200K					
		02:	THRU(Spare)					
		03: Manual White Balance						
Trigger Shutter Mode	04	00:	Normal shutter mode (trigger OFF)					
		01:	Fixed trigger shutter mode (set shutter speed at address 01) Pulse Width Trigger Shutter Mode					
		02:						
Trigger polarity	05	00:	Positive polarity					
		01:	Negative polarity					
Trigger Input	06	00:	CC1					
		01:	12pin connector 11pin input					
Slow shutter	07	0 - FF:	All-pixel mode					
			min:0(0H) - max:255(FFH) 0: OFF, 255: +255 frame time					
			1 frame =					
			2Tap Base Configuration : 9.953ms					
			3Tap Base Configuration (HS) : 6.635ms					
			* In partial scan mode, the total number of frames set for several					
			hours					
			is the frame time.					
			Decimation and addition mode					
			min:0(0H) - max:255(FFH) 0: OFF, 255: +255 frame time					
			1 frame =					
			2Tap Base Configuration : 3.125ms					
			3Tap Base Configuration (HS) : 1.91ms					
			* In partial scan mode, the total number of frames set for several					
			hours					
			is the frame time.					
Scanning Modes	08	00:	Full Frame Scan Mode					
		01:	Partial Scan Mode					
		02: 1/2 Horizontal and Vertical Thinning Mode						
		03:	2 × 2 Horizontal and Vertical Pixel Addition Mode					
Camera Output Mode	0A	00:	2Tap Base Configuration					
(*1)		01:	3Tap Base Configuration HS mode					
Output bit selection	0B	00:	8-bit output					
		01: 10-bit output						
		02:	12-bit output					

 $^{\ast}1$  When changing the settings, save the data and restart the camera.

function	Address	Data (Hex)		
	(Hex)		1	
baud rate	10	00:	9600bps	
(*2)		01: 19200bps		
		02:	38400bps	
		03:	57600bps	
		04:	115200bps	
Trigger Hsync Mode	17	00:	OFF	
		01:	ON	
Output image upside down, left	18	00:	normal	
and right flip		01:	Upside down	
		02:	Flip left and right	
		03:	Upside down, left, right	
背面LED ON/OFF	1B	00:	OFF	
		01:	ON	
Manual Gain	20-21	0 - 78:	min:0(0H) - max:120(78H) 0: x1(0dB), 120: x4(+12dB)	
Manual shutter	24-25	LLHH:	All-pixel mode	
			min:0(0H) - max:1114(45AH)	
			2Tap Base Configuration	
			Shutter time = $14.26us + (1115 - (set)) \times 8.808us$	
			min:0=9.84ms(1/100.47s), max:1115=23.07us(1/40000s)	
			3Tap Base Configuration (HS)	
			Shutter time = 14.26us + (1115 - (set)) × 5.872us	
			min:0=6.562ms(1/15071s), max:1115=20.13us(1/45000s)	
			Decimation and addition mode	
			min:0(0H) - max:570(23AH)	
			2Tap Base Configuration	
			2Tap Base Configuration Shutter Time = $14.26us + (571 - (set)) \times 5.333us$	
			min: $0=3.059ms(1/320s)$ , max: $570=1.959us(1/51000s)$	
			3Tap Base Configuration (HS)	
			Shutter Time = $14.26$ us + $(571 - (set)) \times 3.259$ us	
			min:0=1.875ms(1/523s), max:570=17.52us(1/57000s)	

\*2 Changes to the settings will take effect after the camera is restarted. (Data will be saved automatically)

\* LLHH: The data to be set in 2Byte is set in the order of Low Byte Data and High Byte Data.

< Configuration Example > When setting 1114 (045A H) for the manual shutter (address 24-25) STX SR 24 5A 04 ETX

	-				
function	Address	Data (Hex)			
	(Hex)				
Manual White Balance R	28-29	LLHH:	min:0(0H) - max:767(2FFH) 0: x1(0dB), 767: x4(+12dB)		
(Color only)					
Manual White Balance B	2A-2B	LLHH:	min:0(0H) - max:767(2FFH) 0: x1(0dB), 767: x4(+12dB)		
(Color only)					
Manual White Balance G	2C-2D	LLHH:	min:0(0H) - max:767(2FFH) 0: x1(0dB), 767: x4(+12dB)		
(Color only)					
Partial Scanning	40-41	LLHH:	min:0(0H) - max:1084(43CH)		
Starting Position			* Please set the setting value to a <b>value of 4 x n.</b>		
Partial Scanning	42-43	LLHH:	min:4(4H) - max:1084(43CH)		
Starting Position 2			* Please set the setting value to a <b>value of 4 x n.</b>		
Partial Scanning	50-51	LLHH:	min:4(4H) - max:1088(440H)		
Number of Effective Lines			* When not in use, set the number of effective lines = 1088 (440H).		
			* To enable partial scanning, set the data at address 08 to 01.		
			Please.		
Partial Scanning	52-53	LLHH:	min:4(4H) - max:1084(43CH)		
Number of effective lines: 2			* When not in use, set the number of effective lines = 1083 (43CH).		
			* To enable partial scanning, set the data at address 08 to 01.		
			Please.		

11. Dimensions







(Unit: mm)

# 12. Factory Settings

function	address		data
Preset Shutter	01	00:	1/100.47s(OFF)
Preset White Balance (Color Only)	02	00:	THRU
Trigger Shutter Mode	04	00:	Normal shutter mode (trigger OFF)
Trigger polarity	05	00:	Positive polarity
Trigger Input	06	00:	CC1
Slow shutter	07	00:	OFF
Scanning Modes	08	00:	Full Frame Scan Mode
Camera Output Mode	0A	00:	2Tap Base Configuration
Output bit selection	0B	00:	8-bit output
baud rate	10	00:	9600bps
Trigger Hsync Mode	17	01:	ON
Output image up, down, left and right	18	00:	normal
reverse rollers			
LED ON/OFF	1B	01:	ON
Manual Gain	20-21	0000:	0dB
Manual shutter	24-23	0000:	Shutter (OFF)
Manual White Balance R (Color Only)	28-29	0000:	0dB
Manual White Balance B (Color Only)	2A-2B	0000:	0dB
Manual White Balance G (Color Only)	2C-2D	0000:	0dB
Partial Scan Start Position	40-41	0000:	Starting Position 0
Number of Partial Scan Effective Lines	50-51	0440:	Number of effective lines: 1088

#### 13. Warranty Coverage

The warranty period of this product is 3 years from the date of shipment by our company.

During this period, if a failure occurs due to our design or manufacturing, we will repair it free of charge in accordance with the 15th product service.

However, due to negligence in handling by the customer, natural disasters such as fire, earthquake, lightning, wind and flood damage, or other force majeure.

Damage or malfunction is not covered by the warranty.

Repairs after the warranty period has elapsed will be repaired for a fee only if it can be repaired.

#### 14. About CMOS pixel defects

Pixel defects that are noticeable at the time of product shipment are corrected and shipped, but after the product is shipped, the image sensor-specific

Depending on the characteristics, new pixel defects may occur, and some defect levels may increase over time.

This is excluded from the product warranty.

For details of pixel defect correction, please contact our sales department.

# 15. Product Services

If the product does not work properly due to any factor after purchasing the product, please contact the dealer where you purchased it for investigation, analysis, and repair. Please contact us.